Operating Instructions
Knee Tilt Mechanism

Tilt Lock
Lift lever to enter free float mode, push down to lock.

Seat Height
Lift lever upwards to operate gas height adjustment.

Tilt Tension
Counterbalances body weight when in free float. Turn clockwise to increase force.